

# OFM Valves adaptable to Komatsu®



144-49-00050	Safety Valve	D60A-8 (JPN) 45001 - UP	D60E-8 (JPN) 45001 - UP	D65A-8 (JPN) 45001 - UP	D65E-8 (JPN) 45001 - UP	D65P-8 (JPN) 45001 - UP
144-49-16101	Safety Valve	D60F-8 (JPN) 45001 - UP	D60F-8A (JPN) 45001 - UP			
154-40-00070	Steering Relief Valve	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
		D85P-18 (JPN) 2001 - UP	D95S-2 (JPN) 2001 - UP			
154-40-00082	Steering Valve	D135A-2 (JPN) 10301 - UP	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	D85A-21 (JPN) 35001 - 36533	D85A-21 (JPN) 36534 - UP
		D85C-21 (JPN) 36551 - UP	D85E-21 (JPN) 35001 - 3653	D85E-21 (JPN) 36534 - UP	D85P-21 (JPN) 3001 - 3688	D85P-21 (JPN) 3689 - UP
154-63-14001	Quick Drop Valve	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
155-15-00370	Transmission Control Valve	D155A-1 (JPN) 5508 - UP	D155C-1 (JPN) 15686 - UP	D155C-1P (JPN) 15686 - UP	D155C-1P-ZZ (JPN) 15686 - UP	D355C-3 (JPN) 1800 - UP
		D85A-12 (JPN) 10001 - UP	D95S-1 (JPN) 1003 - UP			
195-13-16100	Relief Valve	D155A-1 (JPN) 5508 - UP	D155A-2 (JPN) 50001 - UP	D155C-1 (JPN) 15686 - UP	D155C-1P (JPN) 15686 - UP	D155C-1P-ZZ (JPN) 15686 - UP
		D155W-1 (JPN) 12128 - UP	D355A-3	D355A-3 (JPN) 1010 - UP	D355A-3X (JPN) 1010 - UP	D355A-5 (JPN) 12622 - UP
		D355C-3 (JPN) 1800 - UP	D455A-1 (JPN) 1002 - UP	D85A-12 (JPN) 10001 - UP	D85A-18 (JPN) 25001 - UP	D85C-21 (JPN) 36551 - UP
		D85E-18 (JPN) 25001 - UP	D85P-18 (JPN) 2001 - UP	D95S-1 (JPN) 1003 - UP	D95S-2 (JPN) 2001 - UP	
195-13-16401	Regulator Valve	D155A-1 (JPN) 5508 - UP	D155S-1 (JPN) 1001 - UP	D355A-3	D355A-3 (JPN) 1010 - UP	D355A-3X (JPN) 1010 - UP
		D355A-5 (JPN) 12622 - UP	D455A-1 (JPN) 1002 - UP	D85A-12 (JPN) 10001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
		D85P-18 (JPN) 2001 - UP	D95S-1 (JPN) 1003 - UP	D95S-2 (JPN) 2001 - UP	HD200-2 (JPN) 1002 - UP	
195-40-00080	Steering Valve					
195-40-11600	Steering Valve					
195-61-21230	Seat, Valve	D150A-1 (JPN) 5508 - UP	D155A-1 (JPN) 5508 - UP	D355A-3 (JPN) 1010 - UP	D355A-3X (JPN) 1010 - UP	D355A-5 (JPN) 12622 - UP
		D455A-1 (JPN) 1002 - UP	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP
		D85E-18 (JPN) 25001 - UP	D85P-18 (JPN) 2001 - UP			
700-91-38002	Valve, Ripper	D85A-21 (JPN) 35001 - 3653	D85A-21 (JPN) 36534 - UP	D85A-21B (JPN) 35001 - 3653	D85A-21B (JPN) 36537 - UP	D85E-21 (JPN) 35001 - 36533
		D85E-21 (JPN) 36534 - UP				
701-30-51002	Relief Valve	D60A-8 (JPN) 45001 - UP	D60E-8 (JPN) 45001 - UP	D60P-8 (JPN) 45001 - UP	D60PL-8 (JPN) 45001 - UP	D60S-8 (JPN) 45001 - UP
		D65A-6 (JPN) 20006 - UP	D65A-8 (JPN) 45001 - UP	D65E-6 (JPN) 20295 - UP	D65E-8 (JPN) 45001 - UP	D65P-7 (JPN) 40001 - UP
		D65P-8 (JPN) 45001 - UP	D65S-6 (JPN) 20006 - UP	D65S-7 (JPN) 40001 - UP	D65S-8 (JPN) 45001 - UP	D70LE (JPN) 45200 - UP
		D70LE-8 (JPN) 45200 - UP	D75A-1 (JPN) 50001 - UP	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP
		D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP	D85P-18 (JPN) 2001 - UP		
		D85A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
701-30-99000	Suction and Safety Valve	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
		D85P-18 (JPN) 2001 - UP				
701-31-11002	Ripper Control Valve	D60A-8 (JPN) 45001 - UP	D60E-8 (JPN) 45001 - UP	D65A-6 (JPN) 20006 - UP	D65A-8 (JPN) 45001 - UP	D65E-6 (JPN) 20295 - UP
		D65E-8 (JPN) 45001 - UP	D65P-7 (JPN) 40001 - UP	D70LE (JPN) 45200 - UP	D70LE-8 (JPN) 45200 - UP	D75A-1 (JPN) 50001 - UP
701-31-12005	Ripper Control Valve	D60E-8 (JPN) 45001 - UP	D65A-8 (JPN) 45001 - UP	D65E-8 (JPN) 45001 - UP	D75A-1 (JPN) 50001 - UP	
701-32-27001	Ripper Control Valve	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
701-33-12006	Blade Valve	D60E-8 (JPN) 45001 - UP	D65A-8 (JPN) 45001 - UP	D65E-8 (JPN) 45001 - UP	D65P-8 (JPN) 45001 - UP	
		D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
701-34-11002	Blade Valve	D85P-18 (JPN) 2001 - UP				
701-40-61002	Suction Valve	D150A-1 (JPN) 5508 - UP	D155A-1 (JPN) 5508 - UP	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	D155W-1 (JPN) 12128 - UP
		D355A-3 (JPN) 1010 - UP	D355A-5 (JPN) 12622 - UP	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP
		D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP	D85P-18 (JPN) 2001 - UP		
701-41-11006	Blade Tilt Control Valve	D150A-1 (JPN) 5508 - UP	D155A-1 (JPN) 5508 - UP	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	
701-43-24001	Work Equipment Control Valve	D150A-1 (JPN) 5508 - UP	D155A-1 (JPN) 5508 - UP	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	D355A-3 (JPN) 1010 - UP
		D355A-5 (JPN) 12622 - UP				
701-43-24002	Work Equipment Control Valve	D150A-1 (JPN) 5508 - UP	D155A-1 (JPN) 5508 - UP	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	D355A-3 (JPN) 1010 - UP
702-12-13001	Servo Valve	D355A	D150A-1 (JPN) 5508 - UP	D155	D155A-1 (JPN) 5508 - UP	D355A-5 (JPN) 12622 - UP
		D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP	D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP
		D85P-18 (JPN) 2001 - UP				
702-12-13002	Servo Valve	D355A	D155	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	D355A-3 (JPN) 1010 - UP
702-12-14000	Servo Valve	D355A	D150A-1 (JPN) 5508 - UP	D155	D155A-1 (JPN) 5508 - UP	D155A-2 (JPN) 50001 - UP
		D355A-5 (JPN) 12622 - UP	D455A-1 (JPN) 1002 - UP	D80A-18 (JPN) 25001 - UP	D80E-18 (JPN) 25001 - UP	D80P-18 (JPN) 2001 - UP
		D85A-18 (JPN) 25001 - UP	D85E-18 (JPN) 25001 - UP	D85P-18 (JPN) 2001 - UP		
702-12-14001	Servo Valve	D355A	D155	D155A-2 (JPN) 50001 - UP	D155A-2A (JPN) 57001 - UP	D355A-3 (JPN) 1010 - UP
709-62-31103	Blade Valve	D85A-21 (JPN) 35001 - 3653	D85A-21 (JPN) 36534 - UP	D85A-21B (JPN) 35001 - 3653	D85A-21B (JPN) 36537 - UP	D85E-21 (JPN) 35001 - 36533
		D85E-21 (JPN) 36534 - UP	D85P-21 (JPN) 3001 - 3688	D85P-21 (JPN) 3689 - UP		

### OFM Replacement Parts

OFM Top Line S.r.l.  
Via Canaletta, 3/A - 40053 Bazzano (Bo) Italy  
Tel. +39 051.835911 - www.ofmtopline.it  
vendite@ofm.it - Fax +39 051.833040

All mentioned names and numbers are for reference purpose only

